

Check List

ATR 72-600

MSFS2020

Índice

1	CHECK LIST INITIAL	3
1.1	OVERHEAD	3
1.2	TABLET.....	4
1.3	FMS.....	5
1.4	PUSHBACK	8
1.5	LISTA VERIFICACIÓN – CHECK LIST.....	9
1.6	ARRANQUE MOTORES.....	11
1.7	CHECK LIST PRE FLIGHT.....	12
1.8	EN VUELO.....	13
1.9	PREPARE TO LANDING	13
1.10	AFTER LANDING	14

1 Check List Initial

1.1 Overhead


1	BAT	ON
2	TABLET - AIRCRAFT	Ground Power / Cargo Door / Main DOOR / TAIL PROP
3	EXT POWER	ON
4	BEACON	ON
5	STBY COMPASS	ON
6	DC GEN 1 Y 2	FAULT
7	HYD PWR	LOPR
8	LOGO y WING	ON
9	AC GEN 1y 2	FAULT
10	NO DEVICE	ON
11	LUCES EMERGENCIA	ARM
12	OXYGEN	Check Piloto y Copiloto



OXYGEN



1.2 Tablet



Una vez informado en la FMS




1.3 FMS


1	FMS	ACT
2	INIT	SELEC
3	POS INIT	SELEC
4	INIT POS	GPS POS / SENSORS INIT



5	RETURN	
6	WEIGHT	Informar ZFW y FOB



7	RETURN	
8	TABLET / PAYLOAD	SET



9	RETURN	
10	FPLN INIT	
11	FLT ID	VBDxxx
12	ROUTE	FROM / TO



13	FROM / TO	EXEC
14	SEL	SELEC SALIDA Y DESTINO + SID / STAR



15	SEL NEXT WPT	SELEC LA ULTIMA LINEA DE SALIDA Y AÑADIREMOS LOS PUNTOS NECESARIOS
16	AIRWAY	EXEC
17	RETURN	



18	Revisar plan de vuelo	
19	PERF	TRANS ALT
20	PERF INIT	CRZ ALT / 19000 + airport ALTN
21	Revisar FMS	



1.4 PushBack

1	LLAMADA SERVICIO TIERRA	
---	-------------------------	--

1.5 Lista verificación – check list



Hay que realizar todo el check list





1	BARO	
---	------	--



2	FMS T/O DATA	Tenemos que confirmar
---	--------------	-----------------------



1.6 Arranque motores

1	PUMPS	RUN
2	PROP BRAKE	ON
3	START A/B	
4	START 2	ON
5	START 1	ON





6	EXT PWR	AVAIL
7	OFF START ABORT	
8	CONDICION LEVEL 1	AUTO
9	PROP BRAKE	OFF
10	CONDICION LEVEL 2	AUTO
11	WINDSHIELD	APAGADO
12	PROBES	APAGADOS
13	GROUND POWER EXT - TABLET	OFF
14	PARKING BRAEK	OFF
15	REVERSE	

1.7 Check list pre flight

1	BEFORE TAXI	
2	TRU	ON



3	TRANSPONDER – FMS	BOTÓN SURV
4	TAXI LIGHT	ON
5	PARKING BRAKE	OFF
6	IAS	
7	NAV	
8	HDG	
9	LUCES STROB	ON
10	LUCES LANDING	ON
11	IDENT	ON
12	LIMIT VELOCIDAD	OFF
13	TREN ATERRISAJE	OFF
14	PILOTO AUTOMATICO	YD
15	1000 PIES	POWER WGT – CLIMB
16	AUTO PILOT	ON
17	Flaps	0

1.8 En Vuelo

01	Altitude trans	Baro Standard
----	----------------	---------------

1.9 Prepare to Landing

01	FMS / PERF	Trans Alt / QNH
02	PERF INIT	
03	VNAV	
04	ACTIVAR APP	FMS
05	AJUSTAR ALTITUD y MINIMUS	DH/DMA



06	AJUSTAR ALTITUD y MINIMUS	DH/DMA
07	CHECK LIST	APPROACH
08	APP	ON
09	FLAPS	15
10	TREN ATERRISAJE	ON
11	FLAPS	FULL
12	TAXI	ON
13	REVERSE	ON
13	REVERSE	OFF

1.10 After Landing

01	CHECK LIST	
02	RADAR	STBY
03	FLIGHT CONTROL	LOCKED
04	FLAPS	OFF
05	LAND y STROBE	OFF
06	PROBES y WINDSHIELD	OFF



07	PARKING BRAKE	ON
08	TAXI LIGHTS	OFF
09	BEACON	OFF
10	COND LEVEL	FTR
11	TRANSPONDER	STBY
12	TAIL PROP - TABLET	ON
13	SEAT BELTS	OFF
14	OXGEN	OFF
15	EXT POWER	ON
16	EXTLT - LUCES	OFF
17	EMER EXIT LIGHT	DISARM
18	COND LEVEL	OFF FULL